



No specialized wiring is required, uses Z224FT4 (hardwire/JKT)

**NOTE** Depending upon the type of wiring installation you have selected, install the diodes IN4005 (included) in accordance to the wiring diagram.

Install the microphones away from noise such as ; ventillation ducts, refrigerator, etc...

Additional external microphones are to be hooked-up to the terminal output at the rear of the wall plate. Make sure that the wires are connected properly.

Ex: stranded to neg.(-) / insulated to pos.(+)

You can remove the microphone PCBBoard from it's original wall plate and install it in other devices. Use extreme CAUTION when doing so.

Before powering-up the XP802 unit, make sure that all components are correctly hooked-up, that is, the microphones, the RCA plugs, etc...

- Power consumption: 8.24ma
- Standard flush mount microphones:
  - Omnidirectional
  - Frequency response = 20-12K
  - Sensitivity = -64dB (-42dB+3dB)
  - Current drain + 0.5mA
- Weight: 4 ounces
- Dimensions: Length 5.1" inches Width 2.6" inches Height 1.0" inches